



Party Works Interactive

Interactive Games - Promotions - Entertainment

Bouncy Castle Safety Rules

Children's safety depends upon your personal supervision. It's required at all times.

1. No food, drink, candy, gum, or any sticky substance allowed inside the bounce.
2. Please make sure that all shoes are removed before entering the bounce.
3. No more than six (6) children in the bounce at the same time.
4. To avoid serious injury please make sure that you don't mix toddlers with larger children.
5. In the case that the bounce starts to deflate please remove the children before checking the power problem. Stay calm as the unit has a baffling system to prolong deflation. Calmly ask each child to go directly to the opening of the bounce and remove them one at a time.
6. Please do not let children bounce on the outside step or against the inside walls.
7. Absolutely no flips allowed.
8. No silly string or water pistols allowed inside the bounce.
9. Please make sure that sharp objects are removed from pockets before entering the bounce.
10. Please remove all jewelry and glasses as they may cause an injury.
11. Bounces are not recommended for adults unless you are supervising a toddler inside the unit.
12. Please make sure that the unit does not shift too far from its original location as this may disengage the fan. If shifting occurs, please pull on the corners of the unit to move it back to its original location.
13. The bounce should not be inflated if winds exceed 20 km/hr.
14. Please use common sense at all times.