



Party Works Interactive

Interactive Games - Promotions - Entertainment

Bouncy Castle Set Up Instructions

Setting up the Bounce:

Important Note: Please use caution when lifting bounces. They weigh between 175 to 250 pounds depending on the size of the bounce.

Step 1: Find a flat level area (preferably a grassy area). Place the bounce on the ground where you want the back of the unit to be. Un-hook the strap and place it somewhere it won't get lost.

Step 2: Roll out the bounce. Then un-fold the bounce until it is flat.

Step 3: After the bounce is opened fully, check to see if there are any Velcro Ports or Zippers that need to be closed. Seal the Velcro port by making sure the Velcro port is flat and closed tightly. Some bounces have a small port or a zipper on the bottom corner of the bounce. **CAUTION: Bounce will not fully inflate if a port is open.**

Step 4: Place inflation tube around nozzle of the blower. Wrap the black strap around the outside of the inflation tube and feed the end of the strap through the metal teeth of the clip.

Step 5: Pull strap until it is tight. If the strap is not tight enough it will separate from the blower and come off. Check the strap again once the Bounce is fully inflated

Step 6: Fold the extra inflation port in half and wrap black strap around the outside of the extra inflation tube and feed the end of the strap through the metal teeth of the clip. Pull strap until it is tight.

Step 7: Hook-up 50' extension cord (**DO NOT ADD ADDITIONAL CORDS**) to the blower and turn the blower switch on. The bounce will take a few minutes to fully inflate. **The blower needs to be turned on the entire time to keep the bounce inflated.** Please use the 4 stakes provided to secure the bounce to the ground.

Step 8: Read the load capacity label on the bounce. **Do not exceed the load capacity of the bounce. We recommend no more than 4-8 children at one time depending on age and size of the kids. NEVER operate bounce without adult supervision.**

Taking Down the Bounce:

Step 1: Make sure everyone is outside of the bounce and that all the grass, dirt, debris, etc. is cleaned out of the bounce. **There will be a \$35 charge for any bounce that is deemed excessively dirty.**

Step 2: Turn off the blower. Disconnect the inflation tube from the blower. Open all ports to allow air inside bounce to come out freely. Allow 10 - 15 minutes for the bounce to deflate. After bounce is on the ground step on the areas that still have air in them.

Step 3: Pull all of the sides into the middle of the bounce. You should be able to see the seam of the bottom of the bounce. The flatter you are able to make bounce, the easier it is to roll it up.

Step 4: To fold the Bounce, fold the right side and the left side in towards the center of the bounce. Both the left side and right side should meet in the middle of the bounce.

Step 5: Fold the bounce over one more time (the bounce should now be folded to a quarter of its size).

Step 6: Step on the bounce to flatten it out and squeeze any remaining air out of the bounce. Starting at the front of the bounce, roll it towards the back and make it as tight as you can get it.

Step 7: Once the bounce is completely rolled, place the strap around the bounce and tie it up. Please use caution when loading the bounce back into your vehicle as it is heavy and awkward.